


(050) 741-41-51  
(096) 878-24-20

## Mercedes Benz ML-class (w163): 120 ENGINE WIRING HARNESS

Mercedes spare parts catalog

Merc.com.ua Mercedes ML-class (w163) 163.113 Unit M - engine 612.963 54 ENGINE WIRING HARNESS 120 ENGINE WIRING HARNESS



NO.	DETAIL NUMBER	NAME/ADDITIONAL INFORMATION	QUANTITY	VERSION
-----	---------------	-----------------------------	----------	---------

[Footnotes...](#)

twenty	<a href="#">A9015402107</a>	<b>WIRING</b> HARNESS ENGINE WIRING HARNESS ME9-(KL5/MS5/MD1/MF8)	----	----
twenty	<a href="#">A9015402107</a>	<b>WIRING</b> HARNESS ENGINE WIRING HARNESS MQ6+(494/MF1/KL5)	----	----
twenty	<a href="#">A9015402107</a>	<b>WIRING</b> HARNESS ENGINE WIRING HARNESS ME9+(ZU9/ZJ9)	----	----
twenty	<a href="#">A9015402107</a>	<b>WIRING</b> HARNESS ENGINE WIRING HARNESS	----	----
<del>twenty</del>	<del><a href="#">A9015401607</a></del>	<del><b>WIRING HARNESS KL5</b> +(MS5/MD1/MF8) <b>Replaced by A 9015402207</b> +004A 0075458226 +001A 0015458428 <a href="#">Footnotes...</a></del>	<del>----</del>	<del>----</del>
<del>twenty</del>	<del><a href="#">A9015402207</a></del>	<del><b>WIRING</b> HARNESS ENGINE WIRING HARNESS KL5+(MS5/MD1/MF8) <a href="#">Footnotes...</a></del>	<del>----</del>	<del>----</del>
<del>twenty</del>	<del><a href="#">A9015404407</a></del>	<del><b>WIRING</b> HARNESS ENGINE WIRING HARNESS KL5+(MS5/MD1/MF8) <a href="#">Footnotes...</a></del>	<del>----</del>	<del>----</del>
<del>twenty</del>	<del><a href="#">A9015401707</a></del>	<del><b>WIRING HARNESS KL5-</b> (ME9/MS5/MD1/MF8) <b>Replaced by A 9015402307</b> +004A 0075458226 +001A 0015458428 <a href="#">Footnotes...</a></del>	<del>----</del>	<del>----</del>
<del>twenty</del>	<del><a href="#">A9015402307</a></del>	<del><b>WIRING</b> HARNESS ENGINE WIRING HARNESS KL5-(ME9/MS5/MD1/MF8) <a href="#">Footnotes...</a></del>	<del>----</del>	<del>----</del>
<del>twenty</del>	<del><a href="#">A9015402307</a></del>	<del><b>WIRING</b> HARNESS ENGINE WIRING HARNESS</del>	<del>----</del>	<del>----</del>
<del>twenty</del>	<del><a href="#">A9015404507</a></del>	<del><b>WIRING</b> HARNESS ENGINE WIRING HARNESS KL5-(ME9/MS5/MD1/MF8) <a href="#">Footnotes...</a></del>	<del>----</del>	<del>----</del>
23	<a href="#">A9015400907</a>	<b>WIRING HARNESS KL5</b> Replaced <b>by A 9015400807</b>	----	----
23	<a href="#">A9015400807</a>	<b>WIRING HARNESS WATER SEPARATOR</b> KL5	----	----

26	<a href="#">A1685450928</a>	<b>PLUG</b> BU FUEL RAMPS COMMON-RAIL	EU version only, not the connector for the US version of the ECU	----	----
29	<a href="#">A0005404505</a>	<b>WIRING HARNESS</b>		----	----
32	<a href="#">A1685451028</a>	<b>BODY PIECE. SOCKET</b> CONNECTOR BU		----	----
35	<a href="#">A0115458026</a>	<b>CONTACT</b> SPRING 1.5-2.5 MM2		----	----
38	<a href="#">A0375459728</a>	<b>FRAME WIRING HARNESS</b> CONNECTOR / ENGINE WIRING HARNESS TO A9015401907,2007,2107,2207,2307		----	----
38	<a href="#">A0375459728</a>	<b>FRAME WIRING HARNESS</b> CONNECTOR / ENGINE WIRING HARNESS TO A9015404307,4407,4507,4807		----	----
38	<a href="#">A0375459728</a>	<b>FRAME WIRING HARNESS</b> CONNECTOR / ENGINE WIRING HARNESS TO A9015404807		----	----
41	<a href="#">A0135451426</a>	<b>SPRING CONTACT</b>		----	----
43	<a href="#">A0015458428</a>	<b>BODY PIECE. SOCKET ENGINE HARNESS</b> CONNECTOR TO FRAME HARNESS TO A 9015400207,1407,1507,9409		----	----
43	<a href="#">A0015458428</a>	<b>BODY PIECE. SOCKET ENGINE HARNESS</b> CONNECTOR TO FRAME HARNESS TO A 9015401107,1607,1707		----	----
45	<a href="#">A0075458226</a>	<b>STEK. SOCKET</b> ENGINE HARNESS CONNECTOR ON FRAME HARNESS 0.5-2.5 MM2		----	----
74	<a href="#">A2105408081</a>	<b>BODY PIECE. SOCKET CAMSHAFT</b> POSITION SENSOR		----	----
80	<a href="#">A0115457726</a>	<b>CONTACT SPRING</b> Replaced by A 0005402705		----	----
80	<a href="#">A0005402705</a>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.75 MM2 <a href="#">Footnotes...</a> 774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2 774: A 002 546 15 41 1, 3 MM2 774: A 002 546 16 41 2.0 MM2		----	----
89	<a href="#">A1685452928</a>	<b>socket housing</b> INJECTORS		----	----
95	<a href="#">A0095458226</a>	<b>CONTACT SPRING</b>		----	----

Replaced by A 0005404005

<b>95</b>	<b>A0005404005</b>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 2.5 MM2 <a href="#">Footnotes...</a> 774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2 774: A 002 546 15 41 1, 3 MM2 774: A 002 546 16 41 2.0 MM2	----	----
<b>131</b>	<b>A1685453028</b>	<b>BODY PIECE. SOCKETS SHUT</b> OFF VALVE References: 010: As Ident. number: 50 324054	----	----
<b>137</b>	<b>A0095458126</b>	<b>CONTACT SPRING</b> Replaced by A 0005403805	----	----
<b>137</b>	<b>A0005403805</b>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.75 MM2 <a href="#">Footnotes...</a> 010: According to Ident. number: 50 324054774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2 774: A 002 546 15 41 1, 3 MM2 774: A 002 546 16 41 2.0 MM2	----	----
<b>149</b>	<b>A1685452928</b>	<b>socket chuck</b> body FAN ELEMENT PIPELINE	----	----
<b>152</b>	<b>A0005457680</b>	<b>GASKET SEAL</b>	----	----
<b>155</b>	<b>A0095458126</b>	<b>CONTACT SPRING</b> Replaced by A 0005403805	----	----
<b>155</b>	<b>A0005403805</b>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.75 MM2 <a href="#">Footnotes...</a> 774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2 774: A 002 546 15 41 1, 3 MM2 774: A 002 546 16 41 2.0 MM2	----	----

167	<a href="#">A1685452728</a>	<b>BODY PIECE.</b> INJECTION <b>SOCKETS</b>	----	----
173	<a href="#">A0095458126</a>	<b>CONTACT SPRING</b> Replaced by A 0005403805	----	----
173	<a href="#">A0005403805</a>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.75 MM2 <a href="#">Footnotes...</a> 774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2 774: A 002 546 15 41 1, 3 MM2 774: A 002 546 16 41 2.0 MM2	----	----
185	<a href="#">A1685452528</a>	<b>BODY PIECE. SOCKETS FUEL RAIL</b> PRESSURE SENSOR	----	----
191	<a href="#">A0095458126</a>	<b>CONTACT SPRING</b> Replaced by A 0005403805	----	----
191	<a href="#">A0005403805</a>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.75 MM2 <a href="#">Footnotes...</a> 774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2 774: A 002 546 15 41 1, 3 MM2 774: A 002 546 16 41 2.0 MM2	----	----
203	<a href="#">A2105402081</a>	<b>BODY PIECE. SOCKET WATER</b> TEMPERATURE SENSOR	----	----
203	<a href="#">A2105402081</a>	<b>BODY PIECE. SOCKET</b> FUEL TEMPERATURE SENSOR	----	----
209	<a href="#">A0085456326</a>	<b>CONTACT BUSHING</b> Replaced by A 0005402505	----	----
209	<a href="#">A0005402505</a>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.5 MM2 <a href="#">Footnotes...</a> 774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2	----	----

774: A 002 546 15 41 1, 3 MM2  
774: A 002 546 16 41 2.0 MM2

215	<a href="#">A0195455428</a>	<b>BODY PIECE. Glow</b> plug sockets	----	----
221	<a href="#">A0035452626</a>	<b>BUSHING</b> 4.0 MM2	----	----
223	<a href="#">A2105402181</a>	<b>BODY PIECE. SOCKET</b> OIL SENSOR	----	----
225	<a href="#">A0085456326</a>	<b>CONTACT BUSHING</b> <b>Replaced by</b> A 0005402505	----	----
225	<a href="#">A0005402505</a>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.5 MM2 <a href="#">Footnotes...</a> 774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2 774: A 002 546 15 41 1, 3 MM2 774: A 002 546 16 41 2.0 MM2	----	----
227	<a href="#">A1685401181</a>	<b>SOCKET</b> DISCONNECTION POINT	----	----
230	<a href="#">A2205402881</a>	<b>SOCKET WATER SEPARATOR</b> ME9	----	----
232	<a href="#">A0005402405</a>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.75 MM2 <a href="#">Footnotes...</a>	----	----
235	<a href="#">A2205400681</a>	<b>BODY PIECE. SOCKET</b> PRESSURE SENSOR ME9	----	----
237	<a href="#">A0085456326</a>	<b>TERMINAL SLEEVE</b> ME9 <b>Replaced by</b> A 0005402505	----	----
237	<a href="#">A0005402505</a>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.5 MM2 ME9 <a href="#">Footnotes...</a> 774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2	----	----

774: A 002 546 15 41 1, 3 MM2

774: A 002 546 16 41 2.0 MM2

239	<a href="#">A2104400381</a>	<b>BODY PIECE. Glow</b> sockets	----	----
245	<a href="#">A0065454626</a>	<b>SPRING CONTACT</b> 1.0-2.5 MM2	----	----
251	<a href="#">A0005454780</a>	<b>GASKET SEAL</b>	----	----
253	<a href="#">A0001530842</a>	<b>CONNECTOR EGR</b> VALVE MD1/MF8/MS5	----	----
255	<a href="#">A0005456080</a>	<b>SEALING</b> MD1/MF8/MS5	----	----
270	<a href="#">A0075455626</a>	<b>BODY PIECE. SOCKET ENGINE HARNESS</b> CONNECTION	----	----
271	<a href="#">A0075455126</a>	<b>STEK. SOCKET</b> 0.75 MM2	----	----
272	<a href="#">A0015452783</a>	<b>CAP</b>	----	----
273	<a href="#">A0005459780</a>	<b>GASKET SEAL</b>	----	----
274	<a href="#">A0005461569</a>	<b>PLUG</b>	----	----
275	<a href="#">A1685453028</a>	<b>BODY PIECE. SOCKET CRANKSHAFT</b> POSITION SENSOR	----	----
281	<a href="#">A0095458126</a>	<b>CONTACT SPRING</b> <b>Replaced by</b> A 0005403805	----	----
281	<a href="#">A0005403805</a>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.75 MM2 <a href="#">Footnotes...</a>	----	----
289	<a href="#">A2025407181</a>	<b>BODY PIECE. SOCKET</b> COMPRESS. AIR CONDITIONER	----	----
290	<a href="#">A0005457380</a>	<b>wire seal</b>	----	----
291	<a href="#">A0095452126</a>	<b>BUSHING</b> <b>Replaced by</b> A 0005403205	----	----
291	<a href="#">A0005403205</a>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 1.0 MM2 <a href="#">Footnotes...</a> 774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2 774: A 002 546 15 41 1, 3 MM2 774: A 002 546 16 41 2.0 MM2	----	----



293	<a href="#">A1685453028</a>	<b>BODY PIECE. SOCKET</b> PRESSURE REGULATING VALVE	----	----
299	<a href="#">A0095458126</a>	<b>CONTACT SPRING</b> Replaced by A 0005403805	----	----
299	<a href="#">A0005403805</a>	<b>WIRING HARNESS</b> REPAIR SOLUTION FOR CONTACTS 0.75 MM2 <a href="#">Footnotes...</a> 774: CONNECTORS MUST BE ORDERED ACCORDING TO THE TOTAL WIRE SIZE. REPAIR MANUAL SEE WIS 774: END SEALING SLEEVES: A 001 546 99 41 GREEN 0.7-2.4 mm2 774: A 002 546 00 41 RED 2.0 - 4.0 mm2 774: A 002 546 01 41 BLUE 3.5 - 8.0 mm2 774 : A 002 546 11 41 YELLOW 7.5 - 12.0 MM2 774: BUTT CONNECTORS: A 002 546 13 41 0.5 MM2 774: A 002 546 14 41 0.8 MM2 774: A 002 546 15 41 1, 3 MM2 774: A 002 546 16 41 2.0 MM2	----	----
313	<a href="#">A0015469941</a>	<b>SEALING SLEEVES</b> GREEN 0.7-2.4 MM2	----	----
313	<a href="#">A0025460041</a>	<b>SEALING SLEEVES</b> RED 2.0-4.0 MM2	----	----
313	<a href="#">A0025460141</a>	<b>SEALING SLEEVES</b> BLUE 3.5-8.0 MM2	----	----
313	<a href="#">A0025461141</a>	<b>SEALING SLEEVES</b> YELLOW 7.5-12.0 MM2	----	----
315	<a href="#">A0025461341</a>	<b>connector</b> 0.5 mm2	----	----
315	<a href="#">A0025461441</a>	<b>BUTT</b> CONNECTOR 0.8 MM2	----	----
315	<a href="#">A0025461541</a>	<b>BUTT</b> CONNECTOR 1.3 MM2	----	----
315	<a href="#">A0025461641</a>	<b>BUTT</b> CONNECTOR 2.0 MM2	----	----
317	<a href="#">N000000001116</a>	<b>bolt</b> WIRE TO Cylinder head cover M 6X19	----	----
332	<a href="#">A9019970190</a>	<b>cable tie</b>	----	----
338	<a href="#">A0001501315</a>	<b>PIPE FOR WIRE</b>	----	----
350	<a href="#">A3359970081</a>	<b>KAB. SLEEVE</b>	----	----
353	<a href="#">A0059976290</a>	<b>cable tie</b>	----	----

Mercedes spare parts  
Mercedes spare parts catalog  
Popular Parts  
Accessories  
Selection of spare parts by VIN  
Prices  
Payment, delivery  
Contacts

Original spare parts for Mercedes Benz A-class  
Original spare parts for Mercedes Benz B-class  
Original spare parts for Mercedes Benz C-class  
Original spare parts for Mercedes Benz CL, CLA, CLC, CLK, CLS  
Original spare parts for Mercedes Benz E-class  
Original spare parts for Mercedes Benz G-class  
Original spare parts for Mercedes Benz X-class

Genuine spare parts for Mercedes Benz GL/GLS, GLA, GLC/GLK  
Original spare parts for Mercedes Benz ML/GLE  
Original spare parts for Mercedes Benz R-class  
Original spare parts for Mercedes Benz S-class  
Original spare parts for Mercedes Benz SL, SLK, SLR, SLS  
Original spare parts for Mercedes Benz Sprinter

Original spare parts for Mercedes Benz V-class  
Original spare parts for Mercedes Benz Vaneo  
Original spare parts for Mercedes Benz Viano  
Original spare parts for Mercedes Benz Vito  
Original spare parts for Mercedes Benz Smart  
Original spare parts for Mercedes Benz Citan

Spare parts catalog Mercedes Benz ML-class (w163): Engine wiring harness. Genuine spare parts Mercedes ML-class (w163), online store Merc.com.ua

0.14 sec